



ASGSR 2016



Biomechanical Modeling of Split-leg Squat and Heel Raise on the Hybrid Ultimate Lifting Kit (HULK)

William K. Thompson (presenter)

Christopher A. Gallo

Beth E. Lewandowski

NASA

Kathleen M. Jagodnik

Baylor College of Medicine

Brad T. Humphreys

Justin H. Funk

Nathan W. Funk

ZIN Technologies

John K. DeWitt

KBR/Wyle

American Society for Gravitational and Space Research - Annual Meeting


October 29, 2016



Digital Astronaut Project – Load Configuration



- Same subject, objectives and methods as the preceding Gallo presentation
- These exercises
 - Split-leg squat (SLS)
 - Heel Raise (HR) (still in progress)
- Load configuration analysis is the primary focus of this presentation
- We also have data available for stance and cadence variations





Exercises and Load Configurations



How does the loading method affect localized physiological outcomes on HULK for exercises of interest?

Split-leg squat (SLS)



Free weight
“Gold standard”




HULK
Long Bar



HULK
Harness*

HULK
T-Bar





Heel Raise (HR)

* Yo-yo Technologies
<http://www.yoyotechnologies.com/products/yoyo-squat/>




Major Findings for SLS





Comparison of Live Video and OpenSim Model Kinematics for SLS






SLS Load Configuration Analysis - Kinematics




Hip



Knee

- Harness posture is more “upright” vs. long bar
 - Less hip and knee flexion over the course of the rep
- Hip abduction (not shown) remains <10 deg for all three load cases throughout the movement






SLS Load Configuration Analysis – Ground Reaction Forces



Long Bar




Harness


Target Leg

Back Leg

Normal



Shear




- Harness shifts the subject's load distribution more onto the back foot relative to both long bar and free weight
- Shear forces are higher with the harness




SLS Load Configuration Analysis – Centers of Pressure Loci in Target Foot




Free Weight



Long Bar



Harness




- Long Bar COP locus shifts more laterally toward mid-foot vs. free weight
- Harness COP locus shifts more forward (toward toe) and slightly more medially vs. free weight and long bar




SLS Load Configuration Analysis – Joint Torques (Inverse Dynamics)



Hip



Knee



- Harness exercise produces less hip and knee torque vs. long bar over the course of the rep
- Long bar vs. free weight exhibits only minor differences





SLS Load Configuration Analysis – Kinetics: Hip Muscle Forces and EMG



Muscle Forces



EMG Envelope

Hip Extensors (Glutes)



- Harness reduces estimated muscle forces in agonist muscles
- Consistent with reduction in target leg GRF, joint torque and EMG responses
- MVC normalizations differ among trials since data were acquired on different days

Hip Flexors (RecFem)







SLS Load Configuration Analysis – Kinetics: Knee Muscle Forces and EMG



Knee Extensors (Quads)




EMG Envelope



- Free Weight appears to activate the knee extensors earlier in the lift.
- Harness case shows much less hip extensor activation than the bar cases.
- Harness case shows more uniform knee flexor activation over the course of the lift.

Knee Flexors (Hamstrings)



No data





Discussion of SLS findings to date

- Using the harness (vs. long bar):
 - The subject places more weight on the non-exercising leg and shear GRFs increase
 - COP shifts more forward and medially in the target foot
 - A small (<50 N-m) knee flexion moment occurs in the exercising leg at the top of the movement
 - Range of motion increases (+15%) at both hip and knee joints
 - Peak joint moments decrease in the hip (-29%) and knee (-6%)
 - Peak hip extensor (-37%) and knee extensor (-8%) muscle forces decrease
- These single-subject results suggest that exercise at a higher applied load with the harness may be needed to impart the same exercise stimulus as with the long bar.
- Modeling can help to quantify this difference in other subjects




Preliminary Findings for Heel Raise





Comparison of Live Video and OpenSim Model Kinematics for Heel Raise





- Only kinematic and EMG results will be presented here
- Some key single-tether data are still needed to complete the analyses
- Plan to acquire data in Nov 2016



HR Load Configuration Analysis - Kinematics



- Ranges of motion in the ankle and MTP joint are general highest for the harness
- The subject adopted a motion to lengthen the free weight and T-Bar concentric phases vs. the long bar and harness concentric phases
- There is a noticeable hesitation followed by a punctuated movement when using the T Bar






EMG Comparison for HR



- The shape of the gastrocnemius activation profile is relatively consistent across loading configurations
- MVC normalizations differ among trials since data were acquired on different days





Looking Forward



- Plan to publish load configuration analysis findings when complete
- Incorporate deadlift findings into load configuration analysis (Jagodnik)
- Will continue modeling efforts to inform and support the development of exercise countermeasure devices on NASA deep space missions
- Incorporate predictive models to provide kinematic estimations for situations where motion capture is impractical (e.g., microgravity)



Questions?



Thank you for listening!



Problem Statement

- Given the small size of the MPCV exercise device, will it be able to provide sufficient physiological loading to maintain musculoskeletal performance?
- Advanced Exercise Concepts Project Risk:
 - Single-tether design may limit exercise performance (?)
- Advance Exercise Concepts Project Requirement:
 - The device shall allow the crew member to perform squat, deadlift and heel raise exercises with proper body positioning*




*according to JSC-29558, "Resistive Exercise Description Document"



Biomechanical Modeling and Simulation (M/S)



- Human exercises/movements
- Primarily resistance training
 - Regular squat (SQ)
 - Split-leg squat (SLS)
 - Heel-raise (HR)
 - Deadlift (DL)
- Using measured input data
 - Motion history (kinematics)
 - Ground Reaction Forces (GRF)
 - Device loads
 - Subject's anthropometrics
- Estimate outcomes
 - Muscle forces and moment arms
 - Joint torques
 - Mechanical loads (bones/joints)







Methods: Data Collection



- GRC Exercise Countermeasures Lab (ECL)
- 3 sessions: APR, JUL, OCT 2015
- Mocap, EMG and force data are synced.
 - Motion capture: BTS Smart-D®, 12 camera system, 100 Hz sampling
 - Ground Reaction Forces (GRF): Kistler® Model 9261 force plates, 100 Hz sampling
 - Device loads: load cells internal to HULK
- EMG: BTS FreeEMG 16 wireless sensors
 - 1000Hz sampling
 - Band pass filtered 20-450 Hz
 - Full wave rectified, RMS envelope
 - MVC normalized
- 1 subject for this data set






Methods: EMG



Sensor Muscle location

Blue 1	Tibialis Anterior
Blue 2	Vastus Medialis
Blue 3	Rectus Femoris
Blue 4	Vastus Lateralis
Blue 5	Hip Adductors
Blue 6	Rectus Abdominis
Blue 7	External Obliques
Blue 8	Medial Gastrocnemius
Red 1	Lateral Gastrocnemius
Red 2	Semitendinosus
Red 3	Biceps Femoris
Red 4	Gluteus Maximus
Red 5	Multifidus
Red 6	Longissimus
Red 7	Middle Trapezius
Red 8	Upper Trapezius



• EMG Processing

- Sampling rate = 1000 Hz
- Band pass filtering: 20 to 450 Hz,
- Full-wave rectified and enveloped with RMS calculation
- EMG activation levels (0.0 to 1.0) normalized to the subject's MVC
- MVC tests were performed prior to application of the mocap markers.

- Muscles isolated for testing according to: Hislop HJ, Avers D, Brown M, Daniels and Worthingham's Muscle Testing: Techniques of Manual Examination and Performance Testing, 9th Edition, Elsevier Saunders, St. Louis, MO, 2014.






Methods: Biomechanical Models in OpenSim



*Rajagopal, A., Dembia, C.L., DeMers, M.S., Delp, D.D., Hicks, J.L., and Delp, S.L., "Full body musculoskeletal model for muscle-driven simulation of human gait," (in review, submitted to IEEE Transactions on Biomedical Engineering) (2016).

- OpenSim (Stanford Univ.) is freely available biomechanical simulation software allowing users to
 - Develop models of musculoskeletal structures
 - Create dynamic simulations of movement and kinematics
 - Calculate estimates for muscle and joint kinetics
- Used a modified and scaled version of the Rajagopal* (2016) lower body model from OpenSim



Long Bar HR



Harness Squat



T-Bar Heel Raise



Methods: OpenSim Work Flows



For detailed explanation of the workflow steps, refer to the OpenSim User's Guide.

<http://simtk-confluence.stanford.edu:8080/display/OpenSim/User%27s+Guide>

Model Scaling

Match the model to the subject's anthropometric measurements

Inverse Kinematics (IK)

Compute the **joint angles** that best replicate the marker position history

Inverse Dynamics (ID)

Determine the net **joint forces and joint torques** based on kinematics

Static Optimization (SO)

Extend ID to resolve the net **muscle group forces** at each instant in time

EMG
Validation

(iteration among steps is assumed)



Methods: Statistical Analysis in Matlab



- Determine rep start and stop times from a marker trajectory
- Resample outcomes onto a normalized time vector from 0.0 to 1.0
- Compute ensemble average
- Perform statistical analysis at each increment (μ and σ)

